

IP Installer User's Manual

Version 3.0.6

Nov. 05, 2012

VIEWZ

www.viewzusa.com

Table of Contents

1.	About IP Installer.....	4
2.	Installing and Uninstalling.....	4
2.1.	Installing IP Installer	4
2.2.	Uninstalling IP Installer	7
3.	Using IP Installer	10
3.1.	Starting the Program	10
3.2.	Search Product.....	12
3.3.	Manual Network Setup.....	13
3.3.1.	When one IP device is selected.....	13
3.3.2.	When two or more IP devices are selected.....	14
3.4.	Automatic Network Setup.....	15
3.5.	Using DHCP Server	18
3.6.	Using PPPoE	18
3.7.	Updating Firmware	20
3.8.	Filter Configuration.....	22
3.9.	Live View.....	23

1. About IP Installer

IP Installer is a proprietary utility program exclusively designed for IP PVMZ products supplied by VIEWZ. It enables users of IP PVMZ products to search their network for any IP PVMZ network camera, video server, or network video recorder no matter what IP address it has. By using IP Installer, users will be able to facilitate network setup process for IP PVMZ products deployment.

- Runs on Microsoft Windows operating system (XP, Vista, 7)
- Searching for Network Cameras, Video Servers, and Network Video Recorders
- Capable of firmware updating for IP PVMZ products
- Support automatic and manual IP setup


2. Installing and Uninstalling

2.1. Installing IP Installer

If the program is started from the CD supplied with IP PVMZ products, insert the CD to the ODD tray and check the installation file. If it is download or copied from the Internet or any other media, locate the file from the PC's hard drive. You will see the icon as shown with the file name **IP Installer_Setup_3.0.x.exe**. The actual file name in your case may vary as the version changes. Double click the icon to start installation.




You may see a consent prompt for running this install program, which is an **User Account Control** of the Windows as shown below.




Click **Yes** button, then the following window will be shown on the screen.




To precede the installation, click **Next** button. The following window will be displayed for location to install.



The default location for installation is **C:\Program Files\IP Installer**. It is recommended to install on this folder, but if you want to change it to other location, click **Browse** button to choose a proper path as you'd like. Now click **Install** button. You will see the progress of copying install files to the hard drive as shown below.




When the file copying is done, the following windows will be shown. Click **Finish** button to finish the installation.




2.2. Uninstalling IP Installer

If you want to remove the IP Installer program from your PC, click **Start > All Programs > IP Installer > Uninstall**.




You may see a consent prompt for running this install program, which is an **User Account Control** of the Windows as shown below.




Click **Yes** button, then the following window will be shown on the screen.




Click **Next** button and you will see the following window.



Click **Uninstall** button to start removing the **IP Installer** program from your computer. The following window will be displayed. Click **Finish** button to close the window.





3. Using IP Installer

3.1. Starting the Program











Once **IP Installer** program has been installed on your computer, a shortcut icon should be created on the desktop of your computer. You can start **IP Installer** by double clicking the icon.

Or you can also start the program by clicking **Start > All Programs > IP Installer > IP Installer** as shown below.



After the program is started, the main window of **IP Installer** program will appear on the screen as shown below. There is no network device shown since it is the first time to run the program and nothing has been registered.




	Search Product	Scan the network and show the list of all the IP PVMZ products that IP Installer program found.
	Clear Product List	Clear the IP PVMZ products list created by searching the network.
	Automatic IP Setup	Configure the network setting of selected IP device in Automatic mode.
	Manual IP Setup	Configure the network setting of selected IP device in Manual mode.
	Connect Product Homepage	Connect to the server homepage of the selected IP device.
	Update Firmware	Update the firmware of the selected IP device.
	Filter Configuration	Define the range of MAC and IP addresses to search.

3.2. Search Product



Make sure that your IP PVMZ products are connected to the network, and click the **Search Product** button. A status window will pop up to show the progress of the searching. Wait until it reaches 100%, or you may press **Cancel** button if you will go ahead with the result made until the moment.



After searching is finished, **IP Installer** program will display the notification window of completion of searching. Click **OK** button to clear the window.



If you want to clear the list of the IP Devices from the window, click **Clear Product List** button from the Main Toolbar.

3.3. Manual Network Setup



Configuring the network parameters of the devices in the list can be started either by clicking right mouse button or by clicking **Manual IP Setup** icon on the main **Toolbar**.

Before starting the setup, you first need to choose the one to be configured. You may choose only one device by clicking it, or you can choose two or more devices by clicking one after another while you keep pressing **CTRL** key of your keyboard.

3.3.1. When one IP device is selected..

Network Setup

Mac Address00306F83801F

☒ Server Namedemo(MS)

☒ HTTP Port80

IP Type

☒ Static☐ DHCP☐ PPPoE

☒ Network

IP Address192 . 168 . 250 . 201

Netmask255 . 255 . 0 . 0

Default Gateway192 . 168 . 0 . 1

DNS1168 . 126 . 63 . 1

DNS2168 . 126 . 63 . 2

PPPoE User

PPPoE Password

PPPoE Password Confirm

Wireless information

Auth Mode

ESSID

Scan AP

Encryption

☒ None☐ WEP☐ TKIP☐ AES

WEP Mode

KEY1

KEY2

KEY3

KEY4

WPAPSK

Authentication

Admin Password

Save Configuration Option

☒ Save Configuration☐ Not Saving

Set

Cancel

MAC Address	MAC address of the selected device is shown.
Server Name	Name of the selected IP device.
HTTP Port	HTTP port number of the IP device for web access to homepage.


IP Type	How to assign IP address to the device (Select Static here for Manual IP Setup)						
Network	General network parameters are required in this part. Please contact your network administrator for detail. (IP Address, Netmask, Default Gateway, DNS1, DNS2)						
Wireless Information	<p>Enter the values for connecting to wireless network. Contact your network administrator for details. (Only available for devices with Wireless option)</p> <ul style="list-style-type: none"> • Auth Mode: Choose from Open System, Shared Key, WPAPSK, WPA2PSK. • ESSID: Enter the name of the Access Point to connect to. • Encryption: Choose from None, WEP, TKIP, AES. The selections are dependent on which Authentication mode as below. <table border="1"> <tr> <th>Authentication Mode</th><th>Supported Encryption</th></tr> <tr> <td>Open, Shared</td><td>N/A or WEP</td></tr> <tr> <td>WPAPSK, WPA2PSK</td><td>TKIP, AES</td></tr> </table> <ul style="list-style-type: none"> • WEP Mode: Select either 64-bit or 128-bit modes, or either HEX or ASCII. • KEY1 – 4: Enter WEP Keys accordingly to Key numbers. • WPAPSK: If you chose to use WPASK or WPA2PSK mode in Auth mode, enter here the appropriate TKIP or AES value. The maximum length is 63 ASCII characters. 	Authentication Mode	Supported Encryption	Open, Shared	N/A or WEP	WPAPSK, WPA2PSK	TKIP, AES
Authentication Mode	Supported Encryption						
Open, Shared	N/A or WEP						
WPAPSK, WPA2PSK	TKIP, AES						
Authentication (Admin Password)	<p>Password for the IP device.</p> <p>(Default password for IP PVMZ products is "root" unless already changed)</p>						
Save Configuration Option	<p>Select whether the configured contents is to be saved in the Flash memory or not.</p> <ul style="list-style-type: none"> • Save Configuration: Changed values will be saved in the Flash memory of the device, which means the changes are permanent. • Not Saving: Changed values will not be saved in the Flash memory, which means if the IP device is turned off the changes are lost and the previous setting will be applied back. 						

Click **Set** button to apply the changed values to IP device. If you don't want it, click **Cancel** button.


3.3.2. When two or more IP devices are selected..

You can select two or more IP devices at the same time by click one after another while CTRL key is pressed. The result is shown as below.

To configure the network parameters of those devices, click the right mouse button or click **Manual IP Setup** icon on the main **Toolbar** with multiple IP devices selected as shown above. Then the following window will show up.



You can modify the value of each changeable field by clicking it. The following shows an example of entering a new value to a field.




Model	Model Numbers of the IP devices that you selected.
MAC Address	MAC address of the selected device is shown.
Server Name	Name of the selected IP device.
IP Type	How to assign IP address to the device (Select Static here for Manual IP Setup)
IP address, Netmask, Gateway, DNS1, DNS2	General network parameters are required in this part. Please contact your network administrator for detail.
HTTP Port	HTTP port number of the IP device for web access to homepage.
Password	Password for the IP device. (Default password for IP PVMZ products is " root ")

If you click **Apply to all** button after change just a field of one IP device, the remaining IP devices will have the same value for that parameter. In this case, each device's **Server name** and **IP Address** field will have +1 incremented value added to the original value. For example, if the first IP device has been given the server name of **NetCam** and **Apply to all** button is pressed, it will be automatically changed to **NetCam1** and the next IP device will have **NetCam2** and so on. The same applies to the **IP address** field.

For Password field, the entered information doesn't incremented but will use the same data.

In using **Apply to all**, you can choose which field is affected. Put check marks only on the devices you want to use this automatic action as below.



Click **Save & Close** button to save the changed values in the Flash memory of all the IP devices and close the Network setup window.

3.4. Automatic Network Setup



Configuring the network parameters of the devices in the list can be started either by clicking right mouse button or by clicking **Automatic IP Setup** icon on the main **Toolbar**. Before starting the setup, you first

need to choose the one to be configured. In this setup mode, IP Installer program checks your local network and assigns available IP addresses to the IP devices. You have a choice of using those automatically assigned IP addresses, or you can just enter other IP addresses as you desire.

The screenshot shows the 'Network Setup' window with the following fields and options:

- Mac Address:** 00306F83801F
- Server Name:** demo(MS) (checked)
- HTTP Port:** 80 (checked)
- IP Type:** Static (selected), DHCP, PPPoE
- Network Section (checked):**
 - IP Address:** 192 . 168 . 250 . 201
 - Netmask:** 255 . 255 . 0 . 0
 - Default Gateway:** 192 . 168 . 0 . 1
 - DNS1:** 168 . 126 . 63 . 1
 - DNS2:** 168 . 126 . 63 . 2
- PPPoE Section:**
 - PPPoE User:** [Empty field]
 - PPPoE Password:** [Empty field]
 - PPPoE Password Confirm:** [Empty field]
- Wireless information:**
 - Auth Mode:** [Dropdown menu]
 - Encryption:** None (selected), WEP, TKIP, AES
 - WEP Mode:** [Two dropdown menus]
 - KEY1:** [Selected radio button, empty field]
 - KEY2:** [Empty radio button, empty field]
 - KEY3:** [Empty radio button, empty field]
 - KEY4:** [Empty radio button, empty field]
 - WPAPSK:** [Empty field]
 - ESSID:** Scan AP [Button]
 - ESSID List:** [Large empty text area]
- Authentication:**
 - Admin Password:** [Empty field]
- Save Configuration Option:**
 - Save Configuration:** (selected radio button)
 - Not Saving:** (radio button)
- Buttons:** Set, Cancel

Server Name	Name of the selected IP device.
HTTP Port	HTTP port number of the IP device for web access to homepage.
IP Type	How to assign IP address to the device (Select Static here for Manual IP Setup)
Network	General network parameters are required in this part. Please contact your network administrator for detail. (IP Address, Netmask, Default Gateway, DNS1, DNS2)
Authentication (Admin Password)	Password for the IP device. (Default password for IP PVMZ products is " root ")


Save Configuration Option

Select whether the configured contents is to be saved in the Flash memory or not.

- **Save Configuration:** Changed values will be saved in the Flash memory of the device, which means the changes are permanent.
- **Not Saving:** Changed values will not be saved in the Flash memory, which means if the IP device is turned off the changes are lost and the previous setting will be applied back.

Click **Set** button to apply the changed values to IP device. If you don't want it, click **Cancel** button to restore the previous values.

Note: If your network has more than one IP address classes at the same time, the confirmation window will be displayed as below. You need to choose the one you are going to use for your IP devices.



3.5. Using DHCP Server

If your network has a DHCP server running for assigning IP addresses, you may choose to let it assign IP addresses to the IP devices on the list. To do that, first open the Network Setup window either by **Manual IP Setup** or **Automatic IP Setup** procedure. Choose **DHCP** in IP Type selection, then **IP Address, Netmask, Default Gateway** field in **Network** setup area on the window will be disabled to input as shown below.

The screenshot shows the 'Network Setup' window. At the top, there are fields for 'Mac Address' (00306F83801F), 'Server Name' (demo(MS)), and 'HTTP Port' (80). Below these, the 'IP Type' section has three radio buttons: 'Static', 'DHCP' (which is selected), and 'PPPoE'. The 'Network' section is expanded, showing fields for 'IP Address' (192 . 168 . 250 . 201), 'Netmask' (255 . 255 . 0 . 0), 'Default Gateway' (192 . 168 . 0 . 1), 'DNS1' (168 . 126 . 63 . 1), and 'DNS2' (168 . 126 . 63 . 2). To the right of the 'Network' section are fields for 'PPPoE User', 'PPPoE Password', and 'PPPoE Password Confirm'. Below the 'Network' section is the 'Wireless information' section, which includes 'Auth Mode' (a dropdown menu), 'Encryption' (radio buttons for None, WEP, TKIP, AES), 'WEP Mode' (two dropdown menus), 'KEY1' through 'KEY4' (radio buttons and text boxes), 'WPAPSK' (a text box), 'ESSID' (a text box with a 'Scan AP' button), and 'Authentication' (a text box). At the bottom, there is a 'Save Configuration Option' section with radio buttons for 'Save Configuration' (selected) and 'Not Saving'. Finally, there are 'Set' and 'Cancel' buttons at the bottom right.

For setting up other fields on the setup window, refer to **3.3 Manual Network Setup**. After filling up the fields with appropriate values, click **Set** button to apply the changed values to IP device. If you don't want it, click **Cancel** button to restore the previous values.

3.6. Using PPPoE

If your network environment is based on PPPoE connection, you'll need to choose **PPPoE** on IP Type selection. First open the Network Setup window either by **Manual IP Setup** or **Automatic IP Setup** procedure. Choose **PPPoE** in IP Type selection, then all the fields in **Network** setup area on the window will be disabled. The network settings such as IP Address, Netmask, Default Gateway, DNS are no longer available to enter. You only need to enter the Server Name, HTTP Port number, and login authentication for your PPPoE connection.

Network Setup

Mac Address00306F83801F

☒ Server Namedemo(MS)

☒ HTTP Port80

IP Type

☐ Static☐ DHCP☒ PPPoE

☒ Network

IP Address192 . 168 . 250 . 201

Netmask255 . 255 . 0 . 0

Default Gateway192 . 168 . 0 . 1

DNS1168 . 126 . 63 . 1

DNS2168 . 126 . 63 . 2

PPPoE User

PPPoE Password

PPPoE Password Confirm

Wireless information

Auth Mode

Encryption☒ None☐ WEP☐ TKIP☐ AES

WEP Mode

KEY1☒

KEY2☐

KEY3☐

KEY4☐

WPAPSK

ESSID

Scan AP

Authentication

Admin Password

Save Configuration Option

☒ Save Configuration☐ Not Saving

Set

Cancel

Note: In PPPoE mode, Wireless configuration is not available.

MAC Address	MAC address of the selected device is shown.
Server Name	Name of the selected IP device.
HTTP Port	HTTP port number of the IP device for web access to homepage.
IP Type	How to assign IP address to the device (Select PPPoE in this mode)
PPPoE	User Authentication for PPPoE Connection. <ul style="list-style-type: none">• PPPoE User: Enter User ID.• PPPoE Password: Enter Password for the User ID.• PPPoE Password Confirm: Enter the same Password again.
Authentication (Admin Password)	Password for the IP device. (Default password for IP PVMZ products is "root" unless already changed)
Save Configuration Option	Select whether the configured contents is to be saved in the Flash memory or not. <ul style="list-style-type: none">• Save Configuration: Changed values will be saved in the Flash memory of the device, which means the changes are permanent.• Not Saving: Changed values will not be saved in the Flash memory, which means

if the IP device is turned off the changes are lost and the previous setting will be applied back.

*Note: After setting up the network for the IP devices, make sure the IP devices are accessible on the network from your computer. It can be done by running Live View function of the homepage of the IP device's built-in server. Refer to **3.9 Live View** section for how to do it.*

3.7. Updating Firmware

Once IP devices are searched and shown on the screen as functioning successfully, you can update the firmware of them in IP Installer program. To do that, first check the firmware version of the device, which you can find on the IP Installer window.



In the above picture, the firmware version of this product is 4.12-06 while the latest firmware version available is 4.14-01 as you could see. If you decide to update the firmware, first download the latest firmware into the hard drive of your computer. Unzip the file if it is compressed.

Then select the IP device to be updated on IP Installer window, then click **Update Firmware** button from the toolbar. The following window will be displayed.

Model	Mac Address	IP Address	Server Name	Progress	Status	Password
FW1173-MS-E	00306F83801F	192.168.250.2...	demo(MS)		Ready	

Update
Select option for update with proper password, and then click the button to update firmware.

☒ ALL (Firmware, RAM disk, System, Web)
☐ SYSTEM and WEB
☐ WEB only

Start update


Get version
Enter the password for each columns and click the button to get version of firmware.

Get version


Apply to all Close

You may find the **Password** field is empty on the window shown above. If so, click the Password field of the IP device and enter the proper password for the device. You are not allowed to update the firmware if the correct password is not provided.

After the password is entered, the **Start Update** button will be enabled now. Click the button to see the following window for selecting the firmware files.




Locate the firmware files on the hard drive and click **OK** button. The firmware updating will start.



You can also select multiple IP devices at the same time, and have them start firmware updating in a single step. Select the files to update by using CTRL key as below.

Click **Start Update** button. You will see the update window brought up with multiple IP devices listed.



The rest of the procedure is the same as in the firmware update case for a single IP device.

Note: The detailed information of firmware files and the procedure can be found in IP PVMZ User's Manual.

3.8. Filter Configuration



When you need to search only for the IP device having a specific range of MAC or IP addresses, you can do it by using this feature. To set the search condition, click **Filter Configuration** button on the Toolbar, then the following window will show up on the screen.

The 'Search filter' dialog box has a title bar with a close button (X). Inside, there are two sections: 'Mac Address' and 'IP Range'. The 'Mac Address' section has a checkbox that is checked, followed by six input boxes containing '00', '30', '6F', and two empty boxes. The 'IP Range' section has a checkbox that is unchecked, followed by two groups of four input boxes each, both containing '0', separated by a tilde '~'. At the bottom are 'OK' and 'Cancel' buttons.

The first six HEX characters are already filled with 00:30:6F, which is MAC prefix for VIEWZ's products. Put a checkmark **MAC Address** or **IP Range** to set the range for searching.

You can set the range of IP addresses to scan as shown below. In this example, all the IP devices having MAC address starting with 00:30:6F will be listed on the result window after scanning.


Or you can look for a single IP device having a specific IP address as below.

This screenshot shows the 'Search filter' dialog box with the 'Mac Address' checkbox checked. The six hex input boxes now contain '00', '30', '6F', '83', '08', and '1F'. The 'IP Range' section remains unchanged. The 'OK' and 'Cancel' buttons are at the bottom.

IP Address range for searching can be entered as follows.

This screenshot shows the 'Search filter' dialog box with the 'IP Range' checkbox checked. The IP range input boxes are filled with '192 . 168 . 250 . 0' and '192 . 168 . 250 . 250'. The 'Mac Address' section remains unchanged. The 'OK' and 'Cancel' buttons are at the bottom.

You may even set both MAC Address and IP Range together at the same time.



After setting the searching range as explained above, click **OK** button. Then IP Installer program window will show the searching range on the top right portion of the window as shown below.



To start searching with this condition now, click **Search Product** button on the toolbar. The program will start searching and show the result after a moment.

3.9. Live View

Once searching and configuration on IP devices are done, you should make sure that the IP devices are accessible with the new settings. The best way to do it is by connecting the homepage of each IP device's built-in server, and starting Live View feature.

Select **Go Product Homepage** when you click the mouse right button on the IP device to test.



If you select **Go Product Homepage**, the homepage of that device's built-in server will be opened on a new Web browser window as shown below. This is the same result when you click Connect Product Homepage button from the Main Toolbar.

Click Live View on the top right of the window, then SmartViewer ActiveX program will be started. If you have not installed the SmartViewer program before, it will ask a confirmation to install it. Allow it and you will be able to find out whether the configuration by IP Installer program is properly done.

Note: Refer to SmartViewer User's Manual for detailed information on SmartViewer ActiveX program.